

Installation Instructions

1



After installing the clamp-on bracket to the panel use the box end of the wrench to install the solar bar. (There is not enough room to use the open-end of the wrench.)

2



Slide the wrench under the nut and push up with your wrench.

3



Now turn the wrench to tighten the nut.